

## **Attachment 8**

### **Lost Communication Procedure**

**ATC Communications.** Prior to UAV launch and during the entire flight operation, UAV operators in the Ground Control Station will be in two-way radio contact with KVCV tower on tower frequency 118.35. A ground observer will maintain visual contact with the aircraft at all times while within the Victorville class D airspace, and maintain two-way contact with the UAV Operator to warn of potential hazards. When a chase aircraft is used, the Ground Control Station will be in continuous contact with that aircraft. In the event of lost radio communication with ATC, communications will be re-established to Victorville tower by ground line phone, by cell phone, or if all other means fail, by a physical trip to the tower by a Boeing staff member, who will then reestablish communications.